

Manual, Assembly instruction: Brodit 854877

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the center console panel frame and the console edge, to widen the gap. See arrows in picture. Peel off the cover of adhesive tape on the ProClip.
2. Place the grooved edges on the ProClip against the widened gaps.
3. Press firmly forward on the ProClip face plate so the grooved edges goes into the gaps. Press until you see or hear/feel it snaps into place. Pull out the gap openers.
4. The ProClip is in place.