

Manual, Assembly instruction: Brodit 854880

Center mount



Please read all the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed on any desired place of the dashboard.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and control panel, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Carefully press the angled lower part of the ProClip into the gap next to the gap opener.

2. Slide the ProClip into desired position.

3. Pull out the gap opener. Press the thin end of the gap opener into the gap on the upper side of the dashboard. Press the angled upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.