

Manual, Assembly instruction: Brodit 854885

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed on desired place on the width of the air vents.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap surrounding the center console control panel, to widen the gap.

2. Press the lower angled edge of the ProClip into the gap next to the Gap Opener (Spaltöffner).

3. Press the top of the ProClip forward and at the same time flex it downward so the top part of the ProClip can go in at the top edge of the air vent. Release pressure of the ProClip so it flexes back and the adhesive tape attaches. Remove the Gap Opener (Spaltöffner).

4. The ProClip is in place.