

Manual, Assembly instruction: Brodit 854892

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed at any desired position along the width of the panel. Before attaching the ProClip, consider that the multimedia screen exits almost in a straight angle so that you do not place the ProClip so it blocks the screens way.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the lower angled edge of the ProClip into the gap by the frame surrounding the control panel.
2. Press the top part of the ProClip upward + forward and place it on the lower edge of the air vent.
3. Press firmly so the adhesive tape really fastens.
4. The ProClip is in place.