

Manual, Assembly instruction: Brodit 854895

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel of the adhesive tape covers on the ProClip. Insert the lower angled edge of the ProClip into the seam between the lower inside of the vent and the frame around the vent. It might be easier to start with a corner (see photo).
2. Insert all of the lower angled edge into the seam.
3. Using your thumb and fingers, flex the ProClip together and insert the upper angled edge of the ProClip into the seam between the upper inside of the vent and the frame around the vent.
4. The ProClip is in place.