

Manual, Assembly instruction: Brodit 854899

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed also on the right side, but only as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap surrounding the information display in the central control panel, to widen the gap. Remove the adhesive tape cover on the ProClip. Press the gap opener downward to flex the panel outward. At the same time hook the curved bottom part of the ProClip into the gap next to the gap opener. Remove the gap opener.

2. Press inward/upward on the bottom part of the ProClip to make sure the curved end hooks properly into the gap.

3. Press the angled upper edge of the ProClip forward/upward into the gap between the central console panel and the dashboard.

4. The ProClip is in place.