

Manual, Assembly instruction: Brodit 854902

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the enclosed gap opener into the gap in the upper inside of the air vent, to widen the gap.
2. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the angled top part into the gap next to the gap opener. Remove the gap opener.
3. Press the gap opener into the gap in the lower inside of the air vent. Press the bottom part of the ProClip upward/forward so it flexes. At the same time insert the angled lower edge of the ProClip into the gap next to the gap opener.
4. The ProClip is in place.