

Manual, Assembly instruction: Brodit 854909

Center mount



Please read the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area wherer the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the lower part of the ProClip into the gap between the air vent panel frame and the padded dashboard ledge.
2. Place your index fingers on top of the ProClip and press firmly down and then push the upper part forward so it goes underneath the air vent overhang.
3. Continue to push forward until the edge with the adhesive tape is all the way into the air vent attaching to the "roof" in the air vent.
4. The ProClip is in place.