

Manual, Assembly instruction: Brodit 854914

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the curved upper edge of the ProClip up and into the gap between the padded dashboard overhand and the top edge of the panel surrounding the air vent.
2. Press the thin end of the enclosed gap openers into the gap between the padded part of the dashboard and the center console panel frame, to widen the gap.
3. Place your hands around each side of the ProClip and push so the ProClip flexes upward and then hook the thin lower edge into the gap between the gap openers. Pull out the gap openers.
4. The ProClip is in place. Front and side view.