

Manual, Assembly instruction: Brodit 854915

Angled mount

1.)



2.)



3.)



4.)



Please read all the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between padded part of the the dashboard and the center console panel frame, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the left side of the ProClip into the gap below the gap opener. Pull out the gap opener.
2. Place your fingers behind the right side of the ProClip. Pull and hook the angled edge into the gap.
3. Press firmly forward on the ProClip to make sure the angled edge goes all the way into the gap.
4. The ProClip is in place.