

Manual, Assembly instruction: Brodit 854917

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel of the adhesive tape cover on the ProClip. Press the angled edge on the right side of the ProClip into the seem/gap in the console sidewall.
2. Push firmly on the right side of the ProClip so it flexes towards the stereo. Hook the angled left edge of the ProClip into the gap between the stereo and the center console panel.
3. Press firmly forward on the left side of the ProClip to make sure the angled edge is all the way into the gap.
4. The ProClip is in place.