

Manual, Assembly instruction: Brodit 854920

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the two panels in the right console edge, to widen the gap. Press the curved edge on the right side of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the thin end of the gap opener into the gap between the upper console edge and the center console panel. Push on the right side of the ProClip so it flexes towards the seam gap in the center console area and hooks into the gap below the gap opener.

3. Press firmly down on the left side of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.