

Manual, Assembly instruction: Brodit 854925

Angled mount



Please read the instructions carefully and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Press the thin end of the enclosed gap opener into the gap between the padded part of the dashboard and the dashboard trim, to widen the gap.

2. Press the curved upper edge of the ProClip into the gap next to the gap opener. Then flip the ProClip downward so the curved edge on the upper part of the ProClip hooks into the seam and behind the trim. Pull out the gap opener.

3. Push on the lower part of the ProClip so it flexes forward and the angled lower edge hooks around the edge of the padded dashboard by the glove compartment door. Then close the glove compartment door.

4. The ProClip is in place.