

Manual, Assembly instruction: Brodit 854935

Center mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Insert the enclosed gap opener into the seam between the frame surrounding the center console and the vent panel, to widen the gap.
2. Insert the angled edge on the right side of the ProClip into the opened seam above the gap opener. Remove the gap opener.
3. Insert the gap opener into the seam between the frame surrounding the center console and the cushioned part of the dash to the left of the console frame, to widen the gap.
4. Press forward on the faceplate to flex the angled edge on the left side of the ProClip behind the edge of the center console frame. Listen for the click to ensure the edge attached behind the panel frame. Remove the gap opener and the ProClip is in place.