

Manual, Assembly instruction: Brodit 854936

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Peel off the adhesive tape cover on the ProClip. Press the angled bottom part of the ProClip into the gap between the frame surrounding the air vent and the center console.
2. Press the top part of the ProClip downward + forward so the grooved edge goes into the gap between the frame surrounding the air vent and the dashboard.
3. Press the top part of the ProClip all the way in until it stops, make sure the tape sticks properly.
4. The ProClip is in place.