

Manual, Assembly instruction: Brodit 854937

Center mount, Low

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the center console and the center console paneling, to widen the gap.
2. Press the angled right part of the ProClip into the gap above the gap opener. Remove the gap opener.
3. Press the gap opener into the gap by the left edge of the center console paneling. Press the left part of the ProClip forward, making it flex, so the angled edge hooks around the edge of the console paneling, above the gap opener. Remove the gap opener.
4. The ProClip is in place.