

Manual, Assembly instruction: Brodit 854939

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Adjust the angled of the air vent so it points downward. Remove the adhesive tape covers on the ProClip.
2. Press the angled upper part of the ProClip into the gap on the upper inside of the air vent. Press the ProClip downward so the edge goes all the way into the gap.
3. Press the lower part of the ProClip upwards and place the bent edge into the lower edge of the air vent.
4. The ProClip is in place.