

Manual, Assembly instruction: Brodit 854941

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures carefully before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap between the frame surrounding the control panel and center console, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Press the angled edge of the ProClip into the gap next to the gap opener. Remove the gap opener.
3. Press the gap opener into the gap between the stereo and the control panel. Press the angled lower part of the ProClip into the gap next to the gap opener. Remove the gap opener.
4. The ProClip is in place.