

Manual, Assembly instruction: Brodit 854942

Angled mount NOT for models with R Link.

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures carefully before installing the ProClip.

1. Press the enclosed gap opener into the gap between the control panel and dashboard, to widen the gap.
2. Press the angled right part of the ProClip into the gap above the gap opener. Remove the gap opener.
3. Press the ProClip leftward so the angled left part goes into the gap between the stereo and control panel. Press the edge into the gap thoroughly.
4. The ProClip is in place.