

Manual, Assembly instruction: Brodit 854944

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed Gap Opener (Spaltöffner) into the gap between the air vent and the center console, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Press the angled upper part of the ProClip into the gap between the upper edge of the air vent and the center console.
3. Press the bottom part of the ProClip upwards + forwards so the angled edge goes into the gap next to the Gap Opener (Spaltöffner). Be careful so the gap in the edge of the ProClip is positioned according to the picture, otherwise it won't go all the way in.
4. The ProClip is in place.