

Manual, Assembly instruction: Brodit 854948

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the upper milled edge of the ProClip into the gap between the dashboard and dashboard overhang. Press until the milled edge goes all the way in and the adhesive tape attaches properly.
2. Press the bottom part of the ProClip upwards.
3. Press the milled lower part of the ProClip into the gap in the lower inner edge of the air vent.
4. The ProClip is in place.