

Manual, Assembly instruction: Brodit 854950

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. IMPORTANT, this ProClip can only be placed as shown in the pictures, it cannot be moved sideways.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed Gap Opener (Spaltöffner)s into the gap between the center console panel and the dashboard, to widen the gap. Remove the adhesive tape covers on the ProClip. Press the L-shaped angled upper part of the ProClip into the gap between the Gap Opener (Spaltöffner)s.
2. Press the ProClip downward so the edge goes all the way into the gap. Remove the Gap Opener (Spaltöffner)s.
3. Press the angled lower part of the ProClip into the gap below the panel surrounding the air vents.
4. The ProClip is in place.