

Manual, Assembly instruction: Brodit 854951

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the angled right part of the ProClip into the gap on the center console side wall.
2. Press the ProClip leftwards and hook the u-shaped left part around the edge surrounding the control panel.
3. Press the ProClip rightwards so the edge goes all the way into the gap.
4. The ProClip is in place.