

Manual, Assembly instruction: Brodit 854952

Angled mount Will cover but not block access to airflow control.



Please read all the instructions and look at the pictures before installing the ProClip.

1. Press the angled lower part of the ProClip into the gap underneath the center console.
2. Press the upper part of the ProClip upward/forward so the angled lower edge goes all the way into the gap.
2. Press the angled upper part of the ProClip into the gap between the décor trim and the center console. Press until you hear/feel the edge goes all the way in.
4. The ProClip is in place.