

Manual, Assembly instruction: Brodit 854955

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the center console panel frame and the air vent ledge panel frame, to widen the gap.
2. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin edge with adhesive tape into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
3. Press the thin end of the Gap Opener (Spaltöffner) into the gap between the air vent ledge panel frame and padded part of the upper dashboard. Press + lift the ProClip forward so the upper angled edge goes into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.