

Manual, Assembly instruction: Brodit 854958

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the center console instrument panel and the frame surrounding the panel, to widen the gap. Then hook the curved edge on the right side of the ProClip around the panel edge next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).

2. Press the thin end of the Gap Opener (Spaltöffner) into the gap between the center panel frame and the padded part of the dashboard near the start button, to widen the gap. Then press firmly forward on the left side of the ProClip so it flexes forward and hooks around the panel edge next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).

3. The ProClip is in place.

4. The ProClip is in place.