

Manual, Assembly instruction: Brodit 854960

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed on the right air vent as well.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the center console instrument panel and the frame surrounding the panel, to widen the gap. Then press/hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Flip/rotate the ProClip upward, towards the upper part of the air vent.

3. Press the thin end of the gap opener into the gap between the air vent frame and the padded part of the dashboard above the vent, to widen the gap. Flex the ProClip upward and hook the angled edge on the upper part of the ProClip over the air vent and into the gap, next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.