

Manual, Assembly instruction: Brodit 854961

Angled mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the air vent frame and the padded part of the dashboard, to widen the gap.

2. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the right side of the ProClip into the gap between the two gap openers. Press until you hear/feel it snaps into place. Pull out the gap openers.

3. Press the thin end of one gap opener into the gap between the air vent frame and the frame surrounding the panel, to widen the gap. Press the thin end on the left side of the ProClip into the gap below the gap opener. Pull out the gap opener.

4. The ProClip is in place.