

Manual, Assembly instruction: Brodit 854964

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press + hook the angled edge on the right side of the ProClip around the side panel and into the gap in the sidewall.
2. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the center console panel and the console edge panel frame, to widen the gap.
3. With your fingers behind the faceplate, flex the left angled edge around the console edge and insert the left angled edge into the gap next to the Gap Opener (Spaltöffner). Press forward on the left angled edge to insure it is all the way into the gap. Pull out the Gap Opener (Spaltöffner).
4. The ProClip is in place.