

Manual, Assembly instruction: Brodit 854966

Center mount Will cover some controls on the Technology Package models.



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the padded ledge in the dashboard and the trim below the air vent, to widen the gap. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the thin end of the enclosed gap opener into the gap between the two dashboard sections, to widen the gap. Press forward on the lower part of the ProClip so the angled edge hooks into the gap next to the gap opener. Pull out the gap opener.

3. The ProClip is in place.

4. The ProClip is in place.