

Manual, Assembly instruction: Brodit 854982

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the center console and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press + hook the angled upper edge of the ProClip into the gap next to the Gap Opener (Spaltöffner).
2. Press the ProClip downward and hook the lower angled edge around the edge of the air vent.
3. Press the ProClip forward so the adhesive tape fastens properly. Remove the Gap Opener (Spaltöffner).
4. The ProClip is in place.