

Manual, Assembly instruction: Brodit 854984

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed on desired position on the dashboard.

1. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the gap on the top of the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Take note of the plastic hook + clip in the gap, see the white arrow.

2. Press the upper edge of the ProClip into the gap between the Gap Opener (Spaltöffner) and the hook + clip in the gap.

3. In one continuous motion; press the upper edge forward all the way into the gap and pull the lower edge towards you so the lower angled edge hooks around the upper edge of the air vent. Remove the Gap Opener (Spaltöffner).

4. The ProClip is in place.