

Manual, Assembly instruction: Brodit 854985

Center mount ONLY for models with keyless ignition. Will interfere with key on other models.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts: Part 1: Attaching part (the smallest part) Part 2: ProClip face plate

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap under the Start button, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on Part 1. Press the angled edge on Part 1 into the gap next to the Gap Opener (Spaltöffner).

2. Press Part 1 upward + forward, so the angled edge goes all the way into the gap and hooks behind the control panel and the adhesive tape attaches. Pull out the Gap Opener (Spaltöffner).

3. Open up the predrilled holes in Part 2 with a screwdriver. Peel off the adhesive tape cover on Part 2. Place Part 2 onto Part 1 so the holes match and the face plate is on the right side. Attach Part 2 onto Part 1 by using the enclosed screws. While screwing, keep the ProClip in place using your index finger and press it forward + upward with your thumb to ensure the screw goes all the way in and the ProClip attaches correctly.

4. The ProClip is in place.