

Manual, Assembly instruction: Brodit 854986

Angled mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Open the glove compartment. Press the angled lower part of the ProClip into the gap on the bottom of the paneling over the glove compartment. Pull the paneling outward slightly if the gap is difficult to see.

2. Press the top part of the ProClip upwards/forwards so the bottom part goes all the way into the gap.

3. Push the top part of the ProClip into the lower edge of the air vent, push until you hear/feel that the grooved edge goes into place. Close the glove compartment.

4. The ProClip is in place.