

Manual, Assembly instruction: Brodit 854991

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the left corner of the angled upper edge of the ProClip into the gap dividing the dashboard.
2. Press the angled edge all the way into the gap.
3. Press the angled lower edge of the ProClip into the gap above the glove compartment.
4. The ProClip is in place.