

Manual, Assembly instruction: Brodit 854993

Center mount, NOT for Classic.

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the air vent panel and the dashboard overhang, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Press the lower edge of the ProClip into the gap dividing the center console. Press the lower edge all the way in to the gap at the same time as you press the upper part of the ProClip upward + forward.
3. Hook the angled upper edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).
4. The ProClip is in place.