

Manual, Assembly instruction: Brodit 855001

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the upper edge of the ProClip into the upper part of the air vent.
2. Press the lower part of the ProClip upward so the grooved edge can go into the gap.
3. Press the grooved lower part of the ProClip into the gap between the frame surrounding the air vent and dash board.
4. The ProClip is in place.