

Manual, Assembly instruction: Brodit 855004

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the curved upper edge of the ProClip into the gap on top of the dashboard. Press the ProClip downward so the curved edge goes all into the gap.
2. Using both hands: pull the ProClip towards you so the angled lower edge of the ProClip hooks around the upper edge of the storage compartment.
3. Make sure the adhesive tape fastens properly.
4. The ProClip is in place.