

Manual, Assembly instruction: Brodit 855005

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the center control panel and the surrounding frame, to widen the gap.
2. Press the angled left part of the ProClip into the gap below the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).
3. Press the thin end of the Gap Opener (Spaltöffner) into the gap on the other side of the frame surrounding the dashboard. Press the angled right part of the ProClip into the gap. Remove the Gap Opener (Spaltöffner).
4. The ProClip is in place.