

Manual, Assembly instruction: Brodit 855017

Angled mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the padded part of the dashboard and the wood grain panel, to widen the gap.

2. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it click into place.

3. Press the thin end of the other gap opener into the gap between the padded console sidewall and the center panel frame, to widen the gap. Push firmly forward on the left side of the ProClip face plate with your thumb so the grooved edge goes into the gap above the gap opener. Press until you see or hear/feel it click into place. Remove both the gap openers.

4. The ProClip is in place.