

Manual, Assembly instruction: Brodit 855018

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the padded console edge, to widen the gap.

2. Press the angled edge on the left side of the ProClip into the gap below the gap opener. Remove the gap opener.

3. Press the thin end of the gap opener into the gap between the console sidewall and the padded part of the dashboard, to widen the gap. Push firmly forward on the right side of the ProClip face plate so the angled edge flexes forward and hooks into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.