

Manual, Assembly instruction: Brodit 855021

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the first enclosed gap opener into the gap between the padded dashboard ledge and the console panel frame, to widen the gap. Press the second gap opener into the gap between the air vent panel frame and the padded dashboard edge.

2. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press firmly forward in the center of the ProClip so the lower grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it click into place.

3. Press down on top of the ProClip with your fingers and firmly forward with your thumb so the grooved edge on the top part of the ProClip goes into the gap next to the gap opener. Press until you see or hear/feel it click into place. Pull out the gap openers.

4. The ProClip is in place.