

Manual, Assembly instruction: Brodit 855022

Angled mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the upper part of the ProClip onto the lower air vent ledge.
2. Push forward on the lower part of the ProClip with your thumb so the angled edge goes into the seam/gap between the panel sections underneath the dashboard overhang.
3. Press upward on the lower part of the ProClip to make sure the angled edge is all the way into the seam.
4. The ProClip is in place.