

Manual, Assembly instruction: Brodit 855023

Angled mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the ProClip in your hand as shown in the picture. Then press the angled edge on the right side of the ProClip into the gap between the console sidewall and the padded console edge.

2. Flip the ProClip upward so the angled edge on the right side of the ProClip hooks behind the console sidewall edge.

3. Please your index finger behind the ProClip and pull it towards you. Then hook the angled edge over the console edge and into the gap between the console edge and the center console trim.

4. The ProClip is in place.