

Manual, Assembly instruction: Brodit 855026

Angled mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel of the adhesive tape cover on the ProClip. Place the ProClip over the area where it will be attached for proper alignment. Place your finger at the bottom edge to mark the placement.

2. Where your finger is marking the placement, press the lower angled edge of the ProClip into the seam between the padded upper dash and the lower solid part of the dash. The lower edge of the ProClip will hook behind the lower dash panel as you rotate the ProClip upward.

3. Rotate the ProClip upward so the angled edge on the lower part hooks behind the lower dashboard panel. Then pull the upper part of the ProClip upward to hook the angled upper edge of the ProClip over the air vent edge.

4. The seam between the vent frame and inside of the vent is a tight seam. To make the upper angled edge of the ProClip go all the way into the seam between the air vent and the surrounding panel frame, pull the ProClip towards you and press down at the same time. It might need to be wiggled a little. Listen for the click as the ProClip goes into place.