

Manual, Assembly instruction: Brodit 855027

Center mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the dashboard trim and the padded part of the dashboard.

2. Press firmly down on top of the ProClip so it flexes downward and the angled edge hooks around the air vent panel frame edge.

3. The ProClip is in place.

4. The ProClip is in place.