

Manual, Assembly instruction: Brodit 855028

Angled mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the ProClip over the area where it is supposed to be attached for proper alignment

2. Press the angled edge on the lower part of the ProClip into the gap between the two padded dashboard sections.

3. Flip the ProClip upward so the angled edge on the lower part hooks behind the padded dashboard section. Then place your index finger underneath the upper part of the ProClip. Pull upward and hook the angled edge over the air vent edge. Note: to make the angled edge go all the way into the seam between the air vent and the surrounding panel frame pull towards you and press down at the same time

4. The ProClip is in place.