

Manual, Assembly instruction: Brodit 855030

Angled mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the angled right edge of the holder into the gap on the center console side wall.
2. Push the ProClip leftward so the angled right edge goes all the way into the gap and the tape adheres properly.
3. Hook the angled left part of the ProClip into the gap next to the center console control panel.
4. The ProClip is in place.