

Manual, Assembly instruction: Brodit 855032

Angled mount ONLY for models with: Visual Boost and Navigation XL 8.8" screen.



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel of the adhesive tape cover on the ProClip. Place the angled left edge of the ProClip over the ring surrounding the center instrument panel.
2. Push the right side of the ProClip forward, flexing it so the angled right edge hooks around the panel edge surrounding the air vent.
3. The ProClip is in place.
4. The ProClip is in place.