

Manual, Assembly instruction: Brodit 855033

Center mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the upper angled edge of the ProClip into the seam between the frame surrounding the vent and the inside of the vent.
2. Flex the lower edge of the ProClip upward and over the frame around the vent. Insert the lower angled edge of the ProClip into the seam between the frame surrounding the vent and the inside of the vent.
3. Press upward on the upper edge of the ProClip and down on the lower edge of the ProClip to ensure the edges go into the seam and the tape adheres to the surfaces.
4. The ProClip is in place.